

Instruction book for Stationary Compressors

SF1 - SF2 - SF4 - SF6T - SF8T

Registration code

Collection: APC SF
Tab: 38
Sequence: 990

Replaces
2920 1130 04

No. 2920 1130 05

1997-06

This instruction book meets the requirements for instructions specified by the machinery directive 89/392/EEC and is valid for CE as well as non-CE labelled machines



Industrial Air Division - B-2610 Wilrijk - Belgium



This instruction book describes how to handle the machines to ensure safe operation, optimum efficiency and long service life.

Read this book before putting the machine into operation to ensure correct handling, operation and proper maintenance from the beginning. The maintenance schedule comprises measures for keeping the machine in good condition.

Keep the book available for the operator and make sure that the machine is operated and that maintenance is carried out according to the instructions. Record all operating data, maintenance performed, etc. in an operator's logbook available from Atlas Copco. Follow all relevant safety precautions, including those mentioned on the cover of this book.

Repairs must be carried out by trained personnel from Atlas Copco who can be contacted for any further information.

In all correspondence mention the type and the serial number, shown on the data plate.

For all data not mentioned in the text, see sections "Preventive maintenance schedule" and "Principal data".

The company reserves the right to make changes without prior notice.

Contents

	Page		Page
1. Leading particulars	3	4 Maintenance	22
1.1 General description	3	4.1 Compressor drive motor	22
1.1.1 Compressor element	3	4.2 Preventive maintenance schedule for the compressor	23
1.1.2 Compressor variants	3		
1.2 Air flow	3	5 Adjustments and servicing procedures	24
1.3 Cooling and condensate drain systems	5	5.1 Air pressure switch	24
1.4 Regulating system	5	5.2 Air filter	24
1.5 Air dryer on SF Full-feature	9	5.3 Belt exchange/tensioning	24
1.5.1 Compressed air circuit	9	5.4 Cooler	25
1.5.2 Refrigerant circuit	9	5.5 Safety valve	25
		5.6 Temperature shut-down switch	25
2 Installation	13	6 Problem solving	25
2.1 Dimension drawings	13		
2.2 Installation alternatives for SF Pack/Full-feature ..	18	7 Principal data	27
2.3 Recommendations	19	7.1 Readings on gauge	27
2.4 Electrical connections	19	7.2 Settings of temperature switch and safety valve ..	27
2.4.1 Installation	19	7.3 Cable size and settings of motor overload relay and fuse	27
2.4.2 Connection of drive motor	19	7.3.1 For SF Standard/Skid/Twin	27
2.4.3 Supply cable	19	7.3.2 For SF Pack and Full-feature - 50 Hz	27
2.5 Pictographs	20	7.3.3 For SF Pack and Full-feature - 60 Hz	28
3 Operating instructions	21	7.4 Reference conditions/limitations	28
3.1 Initial start-up	21	7.5 SF1-2-4 Standard/Skid - 50 Hz	29
3.2 Starting	21	7.6 SF1-2-4 Pack/Full-feature - 50 Hz	29
3.3 During operation	21	7.7 SF2-4 Pack/Full-feature - 60 Hz	29
3.4 Stopping	22	7.8 SF6T-8T Twin - 50 Hz	30
3.5 Taking out of operation at end of compressor service life	22	7.9 Conversion list of SI units into US/British units ..	30


1 LEADING PARTICULARS

1.1 General description

SF are stationary, single-stage, oil-free compressors. They are air-cooled. The power from the drive motor is transmitted to the compressor element through one or two belts.

1.1.1 Compressor element (Fig. 1)

The compressor element consists of a fixed scroll-shaped housing and a scroll-shaped rotor. Air enters the compressor element through inlet opening (1). Once the air is drawn in, the orbiting scroll (4) seals the inlet opening and forces the air into a continuously decreasing space. As scroll (4) keeps orbiting, this process of compression is constantly repeated, resulting in discharging of oil-free compressed air through outlet opening (3).



1. Air inlet
2. Fixed scroll
3. Compressed air outlet
4. Orbiting scroll

Fig. 1. Compressor element

1.1.2 Compressor variants

SF compressors have following main components (Figs. 2 and 3):

- compressor element (E)
- air filter (AF)
- drive motor (M1)
- check valve (CV)
- temperature shut-down switch (TSHH11)
- air cooler (Ca) and cooling fan (FN1)

Check valve (CV) prevents blow-back of compressed air when the compressor is stopped. Temperature shut-down switch (TSHH11) and safety valve (SV) protect the compressor against overheating and overpressure respectively.

SF Standard (Fig. 2a)

Most of the main components are housed in a hinged bodywork top which serves as silencing hood (4). The hood is mounted on a 120 l air receiver (AR) (a 250 l receiver is available as option). A pressure switch (S2), safety valve (SV), air outlet valve (AV), drain valve (Dm) and pressure gauge (Gp) are fitted to the receiver. A circuit breaker (S1) is also provided.

SF Skid (Fig. 2b)

Most of the main components are housed in a hinged bodywork top which serves as silencing hood (4). The hood is mounted on a frame (5) allowing installation of the compressor at the required spot.

SF Twin (Fig. 2c)

Two compressor modules are mounted on a 250 l or 475 l air receiver (AR). Each module is provided with the main components as described above and has its own pressure switch (S2) and circuit breaker (S1).

SF Pack (Fig. 3a)

The compressor is enclosed in a sound-insulated bodywork. A control panel, pressure switch (PSR19) and safety valve are provided. An electric cubicle is installed behind the front door.

SF Full-feature (Fig. 3b)

SF Full-feature are SF Pack compressors additionally provided with an air dryer of the refrigerant type. The dryer removes moisture from the compressed air. See section 1.5.

An optional electronically controlled condensate drain valve to flush the receiver at pre-set intervals may be installed.

1.2 Air flow (Figs. 2 and 3)

Air is drawn through air filter (AF) into compressor element (E) and is compressed. Compressed air is discharged through air cooler (Ca) and check valve (CV).




Fig. 2a. SF Standard

- AF. Air filter
- AR. Air receiver
- AV. Air outlet valve
- Ca. Air cooler
- CV. Check valve
- Dm. Condensate drain valve
- Gp. Working pressure gauge
- SV. Safety valve
- S1. Circuit breaker
- S2. Air pressure switch
- 1. Air inlet grating
- 2. Pictograph: never carry out any maintenance or repair when the unit is pressurized or the voltage is switched on
- 3. Data plate
- 4. Silencing hood
- 5. Frame

Figs. 2. Compressor variants




Fig. 2b. SF Skid




Fig. 2c. SF Twin

1.3 Cooling and condensate drain systems

SF Standard/Skid/Twin (Figs. 2 and 4)

The compressor element (E) is cooled by fan (FN1). The fan is mounted on the drive shaft of the compressor element. The cooling air is blown over the compressor element and air cooler (Ca) via duct (2).

SF Pack (Fig. 3a)

The compressor element (E) is cooled by fan (FN1). The fan is mounted on the drive shaft of the compressor element. The cooling air is blown over the compressor element and air cooler (Ca) via duct (2). A second fan (FN2), driven by an electric motor, expels warm cooling air from the bodywork.

SF Full-feature (Fig. 5)

The compressor element (E) is cooled by fan (FN1). The fan is mounted on the drive shaft of the compressor element. The cooling air is blown over the compressor element and air cooler via duct (2). A second fan (FN2), driven by an electric motor,

expels warm cooling air from the bodywork. The compressed air circuit of the dryer is provided with a moisture trap (MT) with an automatic condensate drain valve (Da) and a manually operated valve (Dm1).

1.4 Regulating system (Figs. 2 and 3)

The air receiver pressure is kept within limits by pressure switch (S2 or PSR19). The switch is connected to the air outlet and electrically connected in the circuit of drive motor (M1). The switch opens and closes its contacts at pre-set pressures.

When the contacts are closed, the circuit to the drive motor is made: the compressor is operating. The air output is maximum.

When the pressure reaches the pre-set maximum, the circuit to the drive motor is broken, causing the compressor to stop. The air output is stopped.





Fig. 3a. SF Pack

F1098




F1099

- | | |
|---------|--------------------------------|
| AF. | Air filter |
| Ca. | Air cooler |
| E. | Compressor element |
| ER. | Electric cubicle |
| FN1/2. | Cooling fans |
| Gd. | Dewpoint temperature gauge |
| Gp. | Working pressure gauge |
| H1. | On/off lamp |
| M1. | Drive motor |
| PSR19. | Air pressure switch |
| P1. | Hourmeter, motor running hours |
| TSHH11. | Temperature shut-down switch |
| Q1. | On/off switch |
| 1. | Dryer |
| 2. | Belt-tensioning bolt |
| 3. | Lock nut |
| 4. | Belts |
| 5. | Cooling air duct |


Fig. 3b. SF Full-feature

Figs. 3. Compressor variants




- E. Compressor element
- FN1. Cooling fan
- M1. Drive motor
- TSHH11. Temperature shut-down switch
- 1. Belt
- 2. Duct
- 3. Motor hold-down bolt
- 4. Aligning/tensioning bolts

Fig. 4. Drive motor, SF Standard/Skid/Twin



- AF. Air filter
- AV. Air outlet valve
- Ca. Air cooler
- Da. Automatic condensate drain
- Dm1. Condensate drain valve
- E. Compressor element
- FN1/2. Cooling fans
- MT. Moisture trap
- M1. Drive motor
- PSR19. Air pressure switch
- TSHH11. Temperature shut-down switch
- 1. Belt
- 2. Belt-tensioning bolt
- 3. Lock nut
- 4. Cooling air duct

Fig. 5. SF Full-feature



- AI. Wet air inlet
- AO. Dry air outlet
- FN1. Cooling fan
- M1. Refrigerant compressor
- M2. Condenser fan motor
- S3. Fan control switch
- 1. Pressure dewpoint gauge
- 2. Insulating block
- 3. Condensate separator
- 4. Condensate trap
- 5. Automatic condensate drain hose
- 6. Manual condensate drain valve
- 7. Capillary tube
- 8. Condenser cooling fan
- 9. Refrigerant condenser
- 10. Hot gas by-pass valve
- 11. Air/refrigerant heat exchanger/evaporator
- 12. Liquid refrigerant dryer/filter
- 13. Air/air heat exchanger

Figs. 6. Dryer on SF Full-feature

Fig. 6a. Flow diagram




Fig. 6b. Dryer components

F1101

1.5 Air dryer on SF Full-feature (Figs. 6)

1.5.1 Compressed air circuit

Wet compressed air enters heat exchanger (13) and is cooled by the outgoing, cold, dried air. Water in the incoming air starts to condense. The air then flows through heat exchanger (11) where the refrigerant evaporates and withdraws heat from the air. More water in the air condenses. The cold air then flows through moisture trap (3) where the condensate is separated from the air. The condensate is automatically drained through outlet (5). The cold, dried air then flows through heat exchanger (13), where it is warmed up by the incoming air.

1.5.2 Refrigerant circuit

Compressor (M1) delivers hot, high-pressure refrigerant gas which flows through condenser (9) where most of the refrigerant condenses.

The liquid flows through liquid refrigerant dryer/filter (12) to capillary tube (7). The refrigerant leaves the capillary tube at evaporating pressure.

The refrigerant enters evaporator (11) where it withdraws heat from the compressed air by further evaporation at constant pressure. The heated refrigerant leaves the evaporator and is sucked in by the compressor.




Fig. 7a. SF1 Single-phase




Fig. 7b. SF2/4 3-phase

- M1. Drive motor
- S1. Circuit breaker
- S2. Pressure switch
- TSHH11. Temperature shut-down switch

Figs. 7. Service diagrams for SF Standard/Skid/Twin




Fig. 8a. SF1 single-phase - 50 Hz




Fig. 8b. SF2/4 3-phase - 50 Hz




Fig. 8c. SF2/4 3-phase + external supply for dryer - 50 Hz




Fig. 8d. SF2 single-phase - 60 Hz




Fig. 8e. SF2/4 3-phase - 60 Hz

Compressor

- F1/4. Fuses (60 Hz) 1)
- F21. Overload relay
- H1. On/off lamp
- K11. Contactor for dryer 2)
- K21. Contactor
- M1. Drive motor
- M2. Fan motor
- PSR19. Air pressure switch

- P1. Hourmeter, motor running hours
- Q1. On/off switch
- T1. Transformer (60 Hz)
- TSHH11. Temperature shut-down switch
- Y1. Electronic drain (optional)

Air dryer (A1)

- C1. Capacitor
- M1. Refrigerant compressor/motor

- M2. Motor, condenser cooling fan
- S3. Control switch, condenser cooling fan
- S6. Thermal overload switch, motor of refrigerant compressor

- 1) F3/4 only for 230 V Full-feature - 60 Hz
- 2) For 60 Hz Full-feature

Figs. 8. Service diagrams for SF Pack/Full-feature




Fig. 9a. 50 Hz





Fig. 9b. 60 Hz

See legend of Figs. 8

Figs. 9. Cubicles (typical examples)





1. Transport bracket
2. Lock nut
3. Air receiver
4. Compressor frame
5. Bolts

Fig. 10. Transport bracket

2 INSTALLATION


2.1 Dimension drawings (Figs. 11)



Type	[14] Pressure	[15] Approx. mass
SF1-STD	8 BAR	129 kg
SF2-STD	8 BAR	129 kg
	10 BAR	129 kg
SF4-STD	8 BAR	139 kg
	10 BAR	139 kg

20 1989 32

Fig. 11a. Dimension drawing, SF Standard



Type	[14] Pressure	[15] Approx. mass
SF1-SKID	8 BAR	70 kg
SF2-SKID	8 BAR	70 kg
	10 BAR	70 kg
SF4-SKID	8 BAR	80 kg
	10 BAR	80 kg

20 2289 00

Fig. 11b. Dimension drawing, SF Skid




Fig. 11c. Dimension drawing, SF Twin on 250 l receiver




Fig. 11d. Dimension drawing, SF Twin on 475 l receiver




Fig. 11e. Dimension drawing, SF Pack and Full-feature





Fig. 11f. Dimension drawing, SF Pack and Full-feature with optional air receiver

2.2 Installation alternatives for SF Pack/Full-feature (Fig. 12)


The roof panel of the compressor is a fully closed panel, whereas the back panel is provided with ventilation openings. Both panels are interchangeable.

ALTERNATIVE 1

The closed panel is used as roof panel. Ventilation is possible through openings in the back panel. A ventilation space of minimum 200 mm must exist between the compressor and the wall.



ALTERNATIVE 2 (2) COOLING AIR OUTLET (4) IN ROOFPANEL (25)



ALTERNATIVE 3 (3) COOLING AIR OUTLET (4) THROUGH BACK WALL (26)





Fig. 12. Installation proposal

ALTERNATIVE 2

The panel provided with ventilation openings is used as roof panel. This allows the compressor to be placed against a wall.

ALTERNATIVE 3

The closed panel is used as roof panel. Installing the compressor against a wall is allowed if a ventilation opening is provided in the wall behind the compressor. This opening must have following minimum dimensions:

- 555 mm horizontally
- 190 mm vertically

On SF Pack compressors, this opening must be 645 mm above floor level, for SF Pack compressors with optional air receiver, the opening must be 835 mm above floor level.

2.3 Recommendations

1. Install the compressor on a level floor, in a cool but frost-free room which is well-ventilated. The air should be clean. Remove the red-painted transport brackets. **On SF Standard/Twin**, remove transport brackets (1-Fig. 10).

2. **SF Pack and Full-feature** may be installed against a wall. Provide for sufficient cooling. See section 2.2.

3. The maximum total pipe length can be calculated as follows:

$$L = \frac{\Delta P \times d^5 \times P}{450 \times Q_c^{1.85}}$$

L = pipe length in m

ΔP = maximum allowable pressure drop (recommended 0.1 bar)

d = inner diameter of pipe in mm

P = compressor outlet pressure in bar absolute

Q_c = free air delivery of compressor in l/s

4. Ventilation: the inlet grids and fan for compressor room ventilation should be installed in such a way that any recirculation of cooling air to the compressor or dryer is avoided. The air velocity to the grids must be limited to 5 m/s. The maximum allowable pressure drop over the cooling air ducts is 30 Pa. The maximum air temperature at the compressor intake opening is 40°C.

The required ventilation capacity to limit the compressor room temperature can be calculated as follows:

$$Q_v = 0.92 N / \Delta T$$

Q_v = required ventilation capacity in m³/s

N = shaft input of compressor in kW

ΔT = temperature increase in compressor room in °C

5. Connect the compressed air equipment to the air outlet valve (AV-Figs. 2 and 15).

6. Connect condensate drain valve (Dm-Figs. 2) to a sewer. It is recommended to provide a funnel to allow visual inspection of the condensate flow.

If the condensate piping has been led outside the compressor room where it may be exposed to freezing temperatures, the piping must be insulated. The condensate drain pipe(s) from the compressor to the sewer must not dip into the water of the sewer. An optional electronically controlled condensate drain to flush the receiver at pre-set intervals may be installed.

7. An air receiver may be required to limit the number of starts per hour (which is maximum 20).

8. Optional filters can be installed in the pressure line downstream of the air outlet valve, e.g.:

- A DD filter for general-purpose filtration. The filter traps solid particles down to 1 micron.
- A PD filter for filtration down to 0.01 micron. A PD filter must be installed downstream of a DD filter.

2.4 Electrical connections**2.4.1 Installation**

The electrical installation must correspond to the local codes. The mains supply and earthing lines must be of suitable size. See section 7.3.

The installation must be earthed and protected by fuses in each phase. An isolating switch should be installed near the compressor.

2.4.2 Connection of drive motor

On SF2/4 Pack and Full-feature - 230 V and 400 V 50 Hz, (Fig. 8b), the drive motor (M1) has been designed for connection to a 3-phase 400 V or 230 V mains. **The motor is wired ex-factory for the higher voltage.**

For operation at the lower voltage, proceed as follows before connecting the compressor to the mains:

- Open the front door.
- The wires marked U2, V2 and W2 are connected to terminal (O). Loosen these wires and connect each wire to its terminal (U2, V2 and W2 respectively).
- Disconnect wire (10) from terminal (N) and connect it to terminal (230 V).
- Close the front door.

2.4.3 Supply cable

For the size of the supply cable, consult section 7.3.

SF Standard/Skid/Twin (Figs. 7)

Connect the cable to terminals 1 and 3 (single-phase) or to

terminals 1, 3 and 5 (3-phase) of circuit breaker (S1-Figs. 2 and 15). Connect the earthing conductor to the earthing terminal. **SF Twin** have a circuit breaker for each compressor module; provide for each circuit breaker separate supply cables.

SF Pack/Full-feature - 50 Hz (Figs. 8a/8b/8c)

Connect the cable to terminals 1 and 3 (single-phase) or to terminals 1, 3 and 5 (3-phase) of contactor (K21-Fig. 9a). Connect the neutral conductor (if provided) to terminal (N) and the earthing conductor to the earthing terminal.

SF Pack/Full-feature - 60 Hz (Figs. 8d/8e)


Connect the cable to terminals L1 and L2 (single-phase) or to terminals L1, L2 and L3 (3-phase). Connect the earthing conductor to the earthing terminal.

The voltage supply to the dryer of **SF Full-feature** must be 230 V single-phase:

- in case of a 3 x 230 V mains, the dryer supply is branched off between two phase conductors
- for other mains voltages, provide a separate 230 V supply with fuses to the dryer

2.5 Pictographs

Fig. 14 shows typical examples of pictographs which may be used on the machine. Also consult Fig. 13.



F1102

- Gd. Dewpoint temperature gauge
- Gp. Working pressure gauge
- P1. Hourmeter, working hours
- Q1/H1. On/off switch - lamp

Pictographs for

- 1. Working pressure
- 2. Hourmeter
- 3. Compressor off
- 4. Compressor on
- 5. Dewpoint temperature

Fig. 13. Control panel for SF Pack and Full-feature

- 1. Manual condensate drain
- 2. Automatic condensate drain
- 3. Switch off voltage and depressurize compressor before maintenance or repair
- 4. Before connecting compressor electrically, consult instruction book for motor rotation direction
- 5. Torques for steel (Fe) or brass (CuZn) bolts
- 6. Warning, voltage
- 7. Consult Instruction book before greasing
- 8. Never adjust switch if it is depressurized




Fig. 14. Pictographs

3 OPERATING INSTRUCTIONS

Safety precautions

The operator must apply all relevant safety precautions, including those mentioned in this book.

Outdoor/altitude operation

If the compressor is installed outdoors or if the air inlet temperature can be below 0°C (32°F), precautions must be taken. In this case, and also if operating at high altitude, consult Atlas Copco.

3.1 Initial start-up

1. Close air outlet valve (AV-Figs. 2, 5 and 15).
2. Check the setting of the overload relay (F21-Figs. 9) or circuit breaker (S1-Figs. 2 and 15). Check the drive motor connections. Connect the compressor electrically. See section 2.4.
3. Close condensate drain valve (Dm-Fig. 2) (if provided), and **on SF Full-feature** also valve (Dm1-Fig. 5).
4. For **SF Standard/Skid/Twin**, push the "On" button (2-Fig. 15) of circuit breaker (S1).
5. Switch on the voltage. Start and stop the compressor by means of switch (Q1-Fig. 13) or switch (1-Fig. 15). Check the drive motor (M1-Figs. 3 and 4) for correct direction of rotation, which must be counter-clockwise when facing the drive end shaft of the motor. An arrow is provided on the cooling duct. If the rotation direction is wrong, switch off the voltage and reverse two incoming electric lines.


3.2 Starting

On SF Standard/Skid/Twin

1. If an air receiver is installed, check that the condensate drain valve is closed.
2. Open air outlet valve (AV-Figs. 2).
3. Switch on the voltage. Move switch (1-Fig. 15) to "I". The compressor starts.
4. The drive motor will automatically stop and start depending on the air pressure.

On SF Pack/Full-feature

1. If an air receiver is installed, check that the condensate drain valve is closed.
2. **On SF Full-feature**, also close condensate drain valve (Dm1-Fig. 5).
3. Open air outlet valve (AV-Fig. 5).
4. Switch on the voltage.
5. Move toggle switch (Q1-Fig. 13) to position "I". The compressor starts; check that lamp (H1) is alight.
6. The drive motor will automatically stop and start depending on the air pressure.
7. **On SF Full-feature**, the nominal pressure dewpoint (Gd-Fig. 3b) will be reached after a few minutes.



- | | |
|----------------------------|-------------------------|
| AV. Air outlet valve | S2. Air pressure switch |
| Gp. Working pressure gauge | 1. On/off switch |
| SV. Safety valve | 2. On button |
| S1. Circuit breaker | |

Fig. 15. Safety devices for SF Standard/Skid/Twin

Note: The maximum number of compressor starts is 20 per hour.

3.3 During operation

On SF Standard/Skid/Twin

1. Check the unloading and loading pressures (Gp-Figs. 2).
2. Regularly drain the condensate: open drain valve (Dm-Figs. 2) for a few seconds; close the valve after draining.

On SF Pack/Full-feature

1. Check the unloading and loading pressures (Gp-Figs. 3).
2. **On SF Full-feature**, check the pressure dewpoint (Gd-Fig. 3b).
3. If an air receiver is installed, drain the condensate regularly: stop the compressor, switch off the voltage and open the drain valve for a few seconds. **On SF Full-feature**, also open drain valve (Dm1-Fig. 5); close the valves after draining.
4. **On SF Full-feature**, check that condensate is discharged automatically from outlet (Da-Fig. 5) during loading 1).

- 1) The amount of condensate depends on the moisture content of the intake air.

Note: The dewpoint will deviate from nominal when the nominal conditions are exceeded. If the dewpoint remains too high or unstable, consult section 6.

3.4 Stopping

On SF Standard/Skid/Twin

1. Move switch (1-Fig. 15) to "O". The compressor stops.
2. Switch off the voltage.
3. Close air outlet valve (AV-Figs. 2).
4. If an air receiver is installed, open drain valve (Dm-Figs. 2)

On SF Pack/Full-feature

1. Move toggle switch (Q1-Fig. 13) to position "O". The compressor stops.
2. Switch off the voltage.
3. Close air outlet valve (AV-Fig. 5).
4. If an air receiver is installed, open the drain valve. **On SF Full-feature**, also open condensate drain valve (Dm1-Fig. 5).

3.5 Taking out of operation at end of compressor service life

1. Stop the compressor and close the air outlet valve.
2. Switch off the voltage and disconnect the compressor from the mains.
3. Depressurize the compressor. If an air receiver is installed, open its drain valve. **On SF Full-feature**, open manual drain valve (Dm1-Fig. 5).
4. If provided, shut off and depressurize the part of the air net which is connected to the outlet valve. Disconnect the compressor air outlet from the air net.
5. If provided, disconnect the compressor condensate piping from the local condensate drain system.

4 MAINTENANCE

The operator must apply all relevant safety precautions, including those mentioned in this book.

Before starting any repair or maintenance:

1. Switch off the voltage and safeguard against unintentional "switch-on".
2. Isolate the compressor by closing outlet valve (AV-Figs. 2 and 5).
3. For compressors with a separate voltage supply to the air dryer (see section 2.4), make sure that the voltage to the dryer is also switched off.
4. Depressurize the system, if an air receiver is installed, open its drain valve. **On SF Full-feature**, open valve (Dm1-Fig. 5).

On SF Full-feature: when handling refrigerant R134a, special safety precautions must be taken:

- Contact of refrigerant with the skin will cause freezing. Special gloves must be worn.
- Fluid refrigerant will cause freezing of the eyes; therefore, safety glasses are a must.
- Refrigerant R134a is poisonous. Do not inhale refrigerant vapours. Make sure that the working area is adequately ventilated. Maintenance and repair on the refrigerant circuit must only be carried out by qualified personnel.

4.1 Compressor drive motor

Refer to the motor data plate. The motor bearings are greased for life.

4.2 Preventive maintenance schedule for the compressor 1)

The schedule comprises a summary of the maintenance instructions. **Read the respective section before taking maintenance measures. The "longer interval" checks must also include the "shorter interval" checks.** When servicing, replace all disengaged packings, e.g. gaskets, O-rings, washers.

Period 2)	Running hours 2)	See section	See note	Operation
Daily	--	3.3/3.4	--	Drain condensate
"	--	7.6/7.7	--	On SF Full-feature , check dewpoint gauge
Monthly	250	5.2	2	Inspect air filter
3-monthly	500	--	1	Check pressure drop over Atlas Copco filters (optional)
6-monthly	--	5.5	3	Operate safety valve
"	--	--	4	Clean compressor
"	--	--	--	On SF Full-feature , brush or blow off the finned surface of the condenser
"	--	--	--	On SF Full-feature , clean moisture trap internally
Yearly	--	5.5	--	Test safety valve
"	--	--	--	Have electrical components/shut-down switch tested
"	2500	5.2	--	Replace air filter
"	2500	5.3	--	Check tension/condition of V-belt(s)
"	5000	--	5	On SF Full-feature , have ball valve mechanism of moisture trap inspected
"	5000	5.3	--	Replace V-belt(s)
--	7500	--	5	On 10-bar units , clean fan (FN1) and duct. Clean compressor element fins, have seals replaced
--	10000	--	5	On 8-bar units , clean fan (FN1) and duct. Clean compressor element fins, have seals replaced
2-yearly	7500	--	5	On 10-bar units , have bearings greased
"	10000	--	5	On 8-bar units , have bearings greased

- 1) **Use only authorized parts. Any damage or malfunction by the use of unauthorized parts is not covered by Warranty or Product Liability.**
- 2) **Whichever interval comes first.** The local Sales company may overrule the maintenance schedule, especially the service intervals, depending on the environmental and working conditions of the compressor.

Notes:

1. If the pressure drop reaches 0.5 bar, it is strongly recommended to change the filter element as its efficiency is decreasing.
2. Check more frequently if operating in a dusty atmosphere. Check for cleanness and damage. Replace a dirty or damaged filter by a new one.
3. Operate the valve by unscrewing its knurled cap one or two turns. Retighten the cap.
4. Also check the air cooler pipe. If necessary, remove dirt from the finned surface of the pipe by air jet.
5. Consult Atlas Copco.

5 ADJUSTMENTS AND SERVICING PROCEDURES

5.1 Air pressure switch (Fig. 16)

The switch allows the operator to select the stopping pressure and the pressure difference between stopping and starting pressures. The stopping and starting pressures are the opening and closing pressures of the switch. **Adjustment may only be carried out when the air pressure switch is pressurized.**

The stopping pressure is controlled by adjusting screw (2). Turn the screw clockwise to raise the stopping pressure, anti-clockwise to lower it.

The pressure difference between starting and stopping is adjusted by means of adjusting screw (1). The adjustment range is given in Fig. 17. Turn the screw anti-clockwise to reduce the pressure difference, clockwise to increase it.



5.2 Air filter (AF-Figs. 2 and 3)

1. Stop the compressor. Unscrew the wing nut. Remove the filter cover and the filter.
2. Clean the cover, if necessary. Discard damaged filters.
3. Fit a new filter and reinstall the cover.

Example:

- stopping pressure : 7 bar(e)
 - starting pressure : adjustable between 5.8 bar(e) and 3 bar(e)
- Consult sections 7.5 up to 7.8 for the maximum pressure

Fig. 17. Adjustment range, difference between starting and stopping pressures



1. Adjusting screw, pressure difference
2. Adjusting screw, stopping pressure

Fig. 16. Air pressure switch

5.3 Belt exchange/tensioning

In case of two belts, the belts must be replaced as a set, even if only one of them seems worn. Use Atlas Copco belts only. The part number of the belt set is mentioned in the Parts list.

On SF Standard/Skid/Twin (Fig. 4)

1. Loosen motor hold-down bolts (3).
2. Loosen the belt tension by screwing bolts (4) equally and take out the belts.
3. Install new belts in the grooves of the pulleys.
4. Tension the belts by screwing bolts (4) equally. The tension is correct if the deflection is between 5 mm (0.20 in) and 7 mm (0.28 in) when exerting a force of 10 N (2.2 lbf) on the belt midway between the pulleys. Make sure that the pulleys remain aligned. The maximum out-of-line is:
 - maximum parallel out-of-line: 0.5 mm
 - maximum angular out-of-line: 0.5°
5. Tighten bolts (3).
6. Check the belt tension after the first 500 running hours.

On SF Pack and Full-feature (Figs. 3a and 5)

1. Remove the belt protection.
2. Loosen lock nut (3). Loosen the belt tension by screwing bolt (2) and take out the belt(s).
3. Install new belts in the grooves of the pulleys.
4. Tension the belts by screwing bolt (2). The tension is correct if the deflection is between 5 mm (0.20 in) and 7 mm (0.28 in) when exerting a force of 10 N (2.2 lbf) on the belt midway between the pulleys.
5. Tighten lock nut (3). Reinstall the belt protection.
6. Check the belt tension after the first 500 running hours.

5.4 Cooler (Ca-Figs. 2, 3a and 5)

Keep the cooler clean to maintain cooling efficiency. If necessary, remove the dirt from the finned surface of the cooler pipe by air jet.

5.5 Safety valve (SV-Figs. 2a and 15)**Operating**

Operate the safety valve by unscrewing the knurled cap one or two turns. Retighten the cap.

Testing

Note: Testing the valve on the compressor must take no longer than necessary as it means an overload on compressor and drive motor.

1. Close the air outlet valve (AV-Figs. 2 or 5). Depressurize and disconnect the pipe or hose from the outlet valve.
2. Start the compressor and wait until it stops automatically.
3. Switch off the voltage. Remove the cover from the air pressure switch (PSR19-Fig. 3a or 5) or switch (S2-Figs. 2).
4. Turn screw (2-Fig. 16) one turn clockwise. Reinstall the cover.
5. Switch on the voltage, slightly open the outlet valve. The compressor will start automatically.
6. Gradually close the outlet valve while observing gauge (Gp-Figs. 2 or 3). If the safety valve does not open at the pressure specified in section 7.2 or opens before that pressure is reached, it must be replaced. If the compressor stops before the specified opening pressure is reached, repeat the procedure as mentioned from step 3.
7. Readjust the stopping pressure as described in section 5.1.
8. Reconnect the air pipe or hose to the closed air outlet valve.

Warning: No adjustments of the safety valve are allowed.

5.6 Temperature shut-down switch

The switch (TSHH11-Figs. 4 and 5) shuts down the compressor in case of overheating. **On SF Standard/Skid/Twin**, circuit breaker (S1-Fig. 15) will cut out and must be reset by pushing the "On" button (2-Fig. 15).

6 PROBLEM SOLVING

The table helps to solve mechanical problems.

Before starting any repair or maintenance:

1. Switch off the voltage and safeguard against unintentional "switch-on".
2. Isolate the compressor by closing outlet valve (AV-Figs. 2 and 5).
3. For compressors with a separate voltage supply to the air dryer (see section 2.4), make sure that the voltage to the dryer is also switched off.
4. Depressurize the system. **On SF Full-feature**, open drain valve (Dm1-Fig. 5).

Mechanical faults and remedies**1. Compressor does not start**

- a. Switch (Q1 or S2) malfunctioning or loose connection
 - a. Have electrical connections checked. Test switch. Replace if necessary
- b. Thermal overload of switch (Q1) tripped
 - b. Start again after cooling off
- c. Switch (TSHH11), circuit breaker (S1) or overload relay (F21) tripped or out of order
 - c. Test. Reset (S1) or (F21), if necessary. See section 5.6.
- d. Receiver pressure too high, contacts of switch (PSR19 or S2) are open
 - d. Compressor will start when contacts of switch close
- e. Switch (PSR19 or S2) out of order
 - e. Test switch. Replace if necessary

2. Compressor does not stop and/or safety valve blows

- a. Air pressure switch (PSR19 or S2) opens too late or not at all
 - a. Readjust or test switch. Replace, if necessary
- b. Safety valve (SV) opens too soon
 - b. Have valve replaced

3. Pressure difference between stopping and starting cannot be adjusted

- a. Air pressure switch (PSR19 or S2) out of order
 - a. See 1e

4. Compressor capacity or pressure below normal

- a. Air consumption exceeds capacity of compressor
 - a. Check equipment connected
 - b. Choked air filter (AF)
 - b. Remove and check filter. Replace if necessary
 - c. Safety valve (SV) leaking
 - c. Replace valve
 - d. Drive belt(s) slipping
 - d. Check condition of belt(s). Correct or replace as required
 - e. Compressor element (E) out of order
 - e. Consult Atlas Copco

5. Compressor overheating and/or shut down by air temperature switch (TSHH11)

- a. Insufficient compressor cooling
- a. Improve ventilation of compressor room. See section 2. Reset circuit breaker (S1), if necessary. See section 5.6
- b. Cooling fans (FN1 and FN2) out of order
- b. Check and correct. Reset circuit breaker (S1), if necessary. See section 5.6
- c. Temperature shut-down switch (TSHH11) out of order
- c. Replace switch

On SF Full-feature also:**6. Pressure dewpoint too high**

- a. Shortage of refrigerant
- a. Have circuit repaired or recharged
- b. Refrigerant compressor (M1) does not run
- b. See 8
- c. Evaporator pressure is too high
- c. See 9
- d. Condenser pressure is too high
- d. See 7

7. Condenser pressure too high or too low

- a. Fan control switch (S3) out of order
- a. Have switch replaced
- b. Condenser fan motor (M2) out of order
- b. Have fan motor inspected
- c. Ambient temperature too high
- c. Improve ventilation. See section 2. If necessary, draw the cooling air from a cooler room
- d. Condenser externally clogged
- d. Clean condenser

8. Motor of refrigerant compressor stops or does not start

- a. The internal thermic protection (S6) of the motor has tripped
- a. The compressor will restart when the motor windings have cooled down

9. Evaporator pressure is too high or too low

- a. Condenser pressure too high or too low
- a. See 7
- b. Shortage of refrigerant
- b. See 6a

7 PRINCIPAL DATA

7.1 Readings on gauge (Figs. 2 and 3)

Ref.: Gp - Working pressure

Reading: Depending on setting of air pressure switch (PSR19 or S2)

Remarks: Modulates, depending on air consumption, between stopping and starting pressures

7.2 Settings of temperature switch and safety valve

Temperature shut-down switch	Breaks at	Unit	Ref.
Compressor element air outlet temperature	70	°C	TSHH11
Safety valve	Opening pressure	Unit	Ref.
Safety valve	10.5	bar(e)	SV

7.3 Cable size and settings of motor overload relay and fuse

7.3.1 For SF Standard/Skid/Twin

Compressor type	Voltage (V)	Circuit breaker (S1) (A)	Fuse 1) (A)	Recommended mains cable size (mm ²) 2)
SF1	230	12	16	2.5
SF2	230	9	16	2.5
SF2	400	5	16	2.5
SF4	230	15	25	2.5
SF4	400	9	16	2.5
SF6T 3)	230	9/15	16/25	2.5
SF6T 3)	400	5/9	16/16	2.5
SF8T 4)	230	15	25	2.5
SF8T 4)	400	9	16	2.5

7.3.2 For SF Pack and Full-feature - 50 Hz

Compressor type	Voltage (V)	Circuit breaker (S1) (A)	Fuse 1) (A)	Recommended mains cable size (mm ²) 2)
SF1	230 single-phase	11	16	2.5
SF2	200	10	16	2.5
SF2	230	5	16	2.5
SF2	400	5	8	2.5
SF2	500	4	8	2.5
SF4	200	18	20	2.5
SF4	230	9	20	2.5
SF4	400	9	16	2.5
SF4	500	7	10	2.5

- 1) The indicated fuse value is the maximum value with regard to the short circuit protection of the starter. The cable size used may impose fuses of a lower value.
- 2) **SF Twin** have a circuit breaker for each compressor module; provide for each circuit breaker separate supply cables.
- 3) The value before and after the slash refers to the SF2 and SF4 compressor module respectively (see data plate on the module)
- 4) For each compressor module

7.3.3 For SF Pack and Full-feature - 60 Hz

Compressor type	Voltage (V)	Overload relay (F21) (A)	Fuse 1)		Recommended mains cable size (mm ²)
			IEC (A)	CSA/UL (A)	
SF1	230 single-phase	11		15	2.5
SF2	230 single-phase	14		20	2.5
SF2	200	10	16		2.5
SF2	220	9	16		2.5
SF2	230	9	16		2.5
SF2	230	9		15	2.5
SF2	460	5	8		2.5
SF2	460	4		8	2.5
SF2	575	4		8	2.5
SF4	200	16	20		2.5
SF4	220	15	20		2.5
SF4	230	14	16		2.5
SF4	230	14		20	2.5
SF4	460	8	16		2.5
SF4	460	7		10	2.5
SF4	575	6		10	2.5

Extension cables

The size of extension cables (not on cable reel) should be in mm²:

Cable length (m)	Size
0 - 25	2.5
25 - 75	4
75 - 100	6

7.4 Reference conditions/limitations

Reference conditions:

- Air inlet pressure (absolute) 1 bar
- Air inlet temperature 20°C
- Relative air humidity 0%
- Nominal working pressure See values below

Limitations

- Max. working pressure See values below
- Max. ambient temperature 40°C
- Min. ambient temperature 0°C

1) The indicated fuse value is the maximum value with regard to the short circuit protection of the starter. The cable size used may impose fuses of a lower value.

7.5 SF1-2-4 Standard/Skid - 50 Hz 1)

Compressor type	SF1 8 bar	SF2 8 bar	SF4 8 bar	SF2 10 bar	SF4 10 bar
Maximum working pressure bar(e)	8	8	8	10	10
Nominal working pressure bar(e)	7	7	7	10	10
Air temperature at outlet valve for SF Skid, approx. °C	38	45	65	40	60
Air temperature at outlet valve for SF Standard, approx. . . °C	30	32	40	28	40
Motor shaft speed r/min	1430	1430	1430	1430	1430
Shaft input kW	1.5	2.0	3.15	2.1	3.0
Sound pressure level dB(A)	65	69	70	65	65

7.6 SF1-2-4 Pack/Full-feature - 50 Hz 1)

Compressor type	SF1 8 bar	SF2 8 bar	SF4 8 bar	SF2 10 bar	SF4 10 bar
Maximum working pressure for SF Pack bar(e)	8	8	8	10	10
Maximum working pressure for SF Full-feature bar(e)	7.75	7.75	7.75	9.75	9.75
Nominal working pressure 2) bar(e)	7	7	7	10	10
Air temperature at outlet valve for SF Pack, approx. . . . °C	35	40	40	35	35
Air temperature at outlet valve for SF Full-feature, approx. °C	25	27	27	25	25
Motor shaft speed r/min	1410	1430	1430	1430	1430
Shaft input kW	1.5	2.1	3.5	2.1	3.0
Sound pressure level dB(A)	54	58	59	54	54
For SF Full-feature also:					
Refrigerant type	R134a	R134a	R134a	R134a	R134a
Pressure dewpoint, approx °C	2	3	3	2	2

7.7 SF2-4 Pack/Full-feature - 60 Hz 1)

Compressor type	SF1 100 psi	SF2 100 psi	SF4 100 psi	SF2 125 psi	SF4 125 psi
Maximum working pressure for SF Pack bar(e)	8	8	8	9.1	9.1
Maximum working pressure for SF Full-feature bar(e)	7.75	7.75	7.75	8.85	8.85
Nominal working pressure bar(e)	7	7	7	8.6	8.6
Air temperature at outlet valve for SF Pack, approx. . . . °C	35	40	40	35	35
Air temperature at outlet valve for SF Full-feature, approx. °C	25	27	27	25	25
Motor shaft speed 3) r/min	1720	1710	1720	1710	1720
Shaft input for SF Pack kW	1.5	1.95	3.1	2.0	2.9
Shaft input for SF Full-feature kW	1.55	2.0	3.15	2.05	2.95
Sound pressure level dB(A)	54	58	59	54	54
For SF Full-feature also:					
Refrigerant type	R134a	R134a	R134a	R134a	R134a
Pressure dewpoint, approx. 4) °C	2	4	4	2	2

1) At reference conditions

2) 9.75 bar(e) for Full-feature 10 bar compressor

3) 1710 r/min for SF2 single-phase

4) At 20°C / 100% relative humidity

7.8 SF6T-8T Twin - 50 Hz 1)

Compressor type	SF6T 8 bar	SF8T 8 bar	SF6T 10 bar	SF8T 10 bar
Maximum working pressure bar(e)	8	8	10	10
Nominal working pressure bar(e)	7	7	10	10
Air temperature at outlet valve, approx. °C	40	40	40	36
Motor shaft speed r/min	1430	1430	1430	1430
Shaft input kW	5.15	6.3	5.1	6.0
Sound pressure level, 250 l vessel dB(A)	72	72	65	65
Sound pressure level, 475 l vessel dB(A)	73	73	66	66

7.9 Conversion list of SI units into US/British units

1 bar = 14.504 psi	1 kW = 1.341 hp (UK and US)	1 m = 3.281 ft	1 N = 0.225 lbf
1 g = 0.0353 oz	1 l = 0.264 US gal	1 mm = 0.0394 in	1 Nm = 0.738 lbf.ft
1 kg = 2.205 lb	1 l = 0.220 Imp (UK gal)	1 m ³ /min = 35.315 cfm	X °C = (1.8X + 32) °F 2)
1 km/h = 0.621 mile/h	1 l = 0.0353 cu.ft	1 mbar = 0.401 in water column	

1) At reference conditions

2) A temperature difference of 1°C = a temperature difference of 1.8°F

Notes:

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

2920 1130 05